

LED J-bar with timer

Troubleshooting

IMPORTANT

Please do not remove the protective waterproof gel cover from the supplied LED light unit. This gel seals the light unit.

When cleaning the gel cover only use a damp cloth.

Setting the clock

Press and hold the (+) and (-) keys for 3 seconds. The hours on the display will begin to flash. Set the hours using the (+) and (-) keys. Press the (SET) key, the minutes on the display will begin to flash. Set the minutes using the (+) and (-) keys. Press the (SET) key to complete.

NOTE: Clock operates in 24hr mode only.

Setting the timers

Press and hold the (SET) and (+) keys for 3 seconds. The hours on the display will begin to flash and the white (L1) indicator light will switch on. Set the hour that you want the white LEDs to switch on using the (+) and (-) keys. Press the (SET) key, the minutes on the display will begin to flash. Set the minutes using the (+) and (-) keys. Press the (SET) key, the hours on the display will begin to flash. This is the time that the white LEDs will switch off. Repeat for the minutes. Press the (SET) key to finalise the settings. Press and hold the (SET) and (-) keys for 3 seconds. The hours on the display will begin to flash and the blue (L2) indicator light will switch on. Repeat the above process to set the blue LED switching times. Once programmed, the white and blue timers can be switched on/off manually by pressing the (SET) and (+) [white] or (SET) and (-) [blue] keys.

Manual switching

The light unit can be switched manually by pressing the (POWER) key.

This will cycle through the following options:

1. White LEDs only
2. Blue LEDs only
3. All LEDs off
4. All LEDs on

NOTE: Manual setting will override timer settings until the next automated switch. I.e. if L1 and L2 timers are set to operate from 10:00-18:00 and the light is manually switched off at 11:00, the timer will not switch the light unit on again until 10:00 the following day. Conversely, if the light is manually switched on (options 1, 2 or 4) at 19:00, the timers will not switch the light off until 18:00 the following day.

If you are in any doubt about the electrical installation or safety of this product you must consult a qualified electrician.

LIGHT UNIT DOES NOT WORK

1. Ensure switch is in the on position on the light unit.
2. Check if its is plugged into the power supply and the switch is on.